

UNDER GUARD	APPLICATION : MONKEY125 (JB02)
CODE	
632-1300000	
REMARK : FOR STOCK MUFFLER ※Kitaco muffler not usable. (Other maker's muffler not usable)	

• Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

ATTENTIONS (MUST READ)

- UNDER GUARD is for dress-up purpose as well as to minimize the damages when falling down. (Not for complete protection). Not for other use.
 - UNDER GUARD is designed and made exclusive for MONKEY125, do not use on other models. Do not modify the way which is not listed or it will cause damage and trouble.
 - We are not responsible for damages and accidents caused by assembling mistake and improper setting.
 - Please ask mechanic for assembling and setting.
- Ask a specialist at specialty shop if you do not understand the role of the surrounding parts.
- Refer to the manufacturer HONDA service manual for each vehicle when installing
 - Bolts and nuts may get loosen by engine vibration.
- Please check and make sure each part of bolts and nuts are not loose before running.
- This instruction sheet is for the instruction with stock condition.
 - Please contact a mechanic nearby immediately when you find something unusual.
- ※ Metal / resin / alumite products get discolored / rust for ages as well as how to use.



Do not give strong pressure such as using rope and tie-down belt to carry motorcycle. Or it may break grab bar or surrounding parts.



Do not go on the rock with under guard. Maintenance with maintenance stand not possible.

PACKING LIST (Refer to the figures & illustration right side)

FIG	PARTS NAME	CODE	PCS	REMARK
1	UNDER GUARD ASSY	632-1300000A	x1	
2	UNDER GUARD STAY FR BASE (FRONT)	-	x1	
3	UNDER GUARD STAY LH FR (L FRONT)	-	x1	
4	UNDER GUARD STAY LH RR (L REAR)	-	x1	
5	UNDER GUARD STAY RH FR (R FRONT)	-	x1	
6	UNDER GUARD STAY RH RR (R REAR)	-	x1	
7	UNDER GUARD STAY RR CENTER (REAR)	-	x1	
8	BUTTON CAP BOLT M6x15	060-0550015	x9	TORQUE : 10N · m (1.0kgf · m)
9	LOCK NUT 6mm	001-0540006	x2	
10	WASHER 6x13x1.0mm	090-0900006	x11	
11	HEXAGON BOLT M8x15	081-0500015	x2	TORQUE : 20N · m (2.0kgf · m)
12	WASHER 8x16x1.2mm	090-0900008	x2	
13	CAP BOLT M6x15	060-0500015	x2	TORQUE : 10N · m (1.0kgf · m)

HOW TO INSTALL

ADVICE !

Install head light guard temporarily to see adjustment. (Otherwise, not all the bolts & nuts installs smoothly.) Tighten finally, adjusting each bolt & nut.

- Make sure everything is stable before driving.

