## UNI FILTER KIT No,1/1

CODE: 515-1471100

APPLICATION CT125 HUNTER CUB (JA65)

REMARK By changing UNI filter to improve air intake efficiency for enigne. \*FI setting is not required in case of stock engine and muffler combination.

•Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

## ATTENTION (MUST READ)

- This product is for tacing use.
- •This product is replacement for stock air cleaner case when installing Kitaco OIL COOLER KIT, etc.

•We are not responsible for violation of law or damages and accidents caused by assembling mistake and improper setting.

Please follow this instruction sheet. Do not modify the way which is not listed or it will cause damage and trouble.
Please ask authorized mechanic for assembling and setting. Ask a specialist at specialty shop if you do not understand the role of the surrounding parts.

•Refer to the manufacturer service manual when installation.

•Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.

•This product is designed and made exclusive for application models, do not use other models.

※ Metal/resin/alumite products get discolored/rust for ages as well as how to use. Please understand when using.



HOW TO INSTALL			PACKING LIST			
*		FIGURE	NAME C			QTY
		1	UNI FILTER (Ф46)	PK-7E	515-1100100	x1
		2	SILICONE HOSE	UNI /CT125	515-1471101	x1
			JOINT PIPE	Ф45	515-1471102	(x1)
		3	STAY	CT125	515-1471103	x1
*	Removing outer cowls are required to install this product. Refer to the manufacturer service manual when installation.	4	GROMMET	Φ55	515-1471104	x1
		5	BREATHER FILTER	AP-121	515-3010121	x1
		6	HOSE CONNECTOR (I TYPE / Φ8)	BLACK	990-0603080	x1
_		7	GASOLINE HOSE (GRAY)	7.0x60	991-9070060	x1
1	Remove outer cowls to disconnect connecting tube and joint from air cleaner case.	8	STAINLESS BAND (W9)	30-45mm	995-0500045	x1
		9	STAINLESS BAND (W9)	40-60mm	995-0500060	x1
		10	SPACER COLLAR (BK)	6.2x18xL15	093-0800045	x1
2	Install ③ stay to air cleaner case installation bolt position. Install other parts.	11	FLANGE HEXAGON BOLT	M6x12	062-0561012	x2
		12	FLANGE HEXAGON BOLT	M6x30	062-0561030	x1
		13	TIE BAND (MS TIE)	152x3.5	700-9200152	x1
3	Install ② silicone hose to (stock)	14	HOSE CLIP (STAINLESS)	Ф12	995-0601112	x2

 a moult is smooth hose to (atok) connecting tube joint position. (Refer to the illustration,)
 4 Connect the breather tube

removed from air cleaner case to attached (5) breather filter, (6) connector and (7) hose.



3-8-13 NAGATA, HIGASHI-OSAKA, OSAKA,JAPAN https://www.kitaco.co.jp/

240119 M-T

FI setting is not required in case of stock engine and muffler combination.