

SIDE COVER SET			APPLICATION : GROM (JC92)
CODE :			
BK/RD (BLACK/RED) 615-1452020	BK/SL (BLACK/SILVER) 615-1452060	BK/GL (BLACK/GOLD) 615-1452070	
GM/RD (GUNMETAL GRAY/RED) 615-1452120	GM/SL (GUNMETAL GRAY/SILVER) 615-1452160	GM/GL (GUNMETAL GRAY/GOLD) 615-1452170	

● Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

### ATTENTION (MUST READ)

This product is designed and made exclusive for application vehicle, do not use other models. Do not modify the way which is not listed or it will cause damage and trouble.

We are not responsible for violation of law or damages and accidents caused by assembling mistake and improper setting.

Please ask authorized mechanic for assembling and setting.

This instruction sheet is for the instruction for genuine condition. Refer to the manufacturer service manual when installation.

Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.

Metal/resin/alumite products get discolored/rust for ages as well as how to use. Please understand when using.

PACKING LIST (Refer to the figure & illustration below.)					
FIGURE	NAME	CODE	QTY	TORQUE	
1	L SIDE COVER (OUTER)	BK/GM	-	x1	
2	R SIDE COVER (OUTER)	BK/GM	-	x1	
3	INNER PLATE	RD/SL/GL	-	x2	
4	BUTTON CAP BOLT	M5x15	050-0550010	x14	<b>TORQUE : 5.2N·m (0.52kgf·m)</b>
5	WASHER	5x12x0.8	090-0900000	x22	
6	SPRING WASHER	5mm	091-0500005	x8	
7	NUT	5mm	001-0500005	x8	

### HOW TO INSTALL

#### ADVICE!

When installation, tighten bolts and nuts temporarily to adjust each parts. (If tighten firmly while installing temporarily, bolts point might be different, therefore unable to install correctly.) After finished install temporarily, tighten bolts and nuts firmly with specified torque adjusting each parts.

- 1) Refer to the service manual, remove R/L side cover and installation bolt.
- 2) Install R/L side cover and inner plate temporarily with attached bolts.
- 3) Install Kitaco side cover to removed side cover installed place.
- 4) Install side cover temporarily with bolt/washer. (3 places each.)
- 5) Tighten temporarily tightened bolts firmly alternately evenly.

● Make sure not to loosen side cover before riding.

Illustration is R (right side). Please do installation on L (left side) with same process.

