

UNDER GUARD

APPLICATION : GROM (JC92)

CODE

632-1452000

REMARK : FOR GENUINE MUFFLER ※OTHER MAKER'S MUFFLER NOT USABLE.

● Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

ATTENTIONS (MUST READ)

- UNDER GUARD is for dress-up purpose as well as to minimize the damages. (Not for complete protection). Not for other use.
- UNDER GUARD is designed and made exclusive for GROM (JC92), do not use on other models. Do not modify the way which is not listed or it will cause damage and trouble.
- We are not responsible for damages and accidents caused by assembling mistake and improper settling.
- Please ask mechanic for assembling and setting. Ask a specialist at specialty shop if you do not understand the role of the surrounding parts.
- Refer to the manufacturer HONDA service manual for each vehicle when installing.
- Bolts and nuts may get loosen by engine vibration. Please check and make sure each part of bolts and nuts are not loose before running.
- This instruction sheet is for the instruction with stock condition.
- Please contact a mechanic nearby immediately when you find something unusual.
- ※Metal / resin / alumite / products get discolored / rust for ages as well as how to use.

⚠ Do not give strong pressure such as using rope and tie-down belt to carry motorcycle. Or it may break grab bar or surrounding parts.

⊘ Do not go on the rock with under guard. Maintenance with maintenance stand is not possible.

PACKING LIST (Refer to the figures & illustration right side)

図記号	NAME	CODE	QTY	REMARK
1	UNDER GUARD BODY (BODY)	632-1452001	x1	
2	FR BASE STAY (FRONT)	-	x1	
3	L/RH FR SIDE STAY (L/R FRONT)	-	x2	
4	RR BASE STAY (REAR)	-	x1	
5	LH RR SIDE STAY (L REAR)	-	x1	
6	RH RR SIDE STAY (R REAR)	-	x1	
7	HEXAGON PROP 6x30mm	0900-011-06030	x1	TORQUE : 10N・m (1.0kgf・m)
8	BUTTON CAP BOLT M6x15	060-0550015	x6	TORQUE : 10N・m (1.0kgf・m)
9	CAP BOLT M6x15	060-0500015	x6	TORQUE : 10N・m (1.0kgf・m)
10	WASHER 6x13x1.0mm	090-0900006	x15	
11	LOCK NUT 6mm	001-0540006	x2	
12	FLANGE HEXAGON BOLT M8x20	082-0560020	x3	TORPUE : 20N・m (2.0kgf・m)
13	SPRING WASHER 8mm	091-0500008	x3	
14	WASHER 8x16x1.2mm	090-0900008	x3	

HOW TO INSTALL

ADVICE!

Install head light guard temporarily to see adjustment. (Otherwise, not all the bolts & nuts installs smoothly.) Tighten finally, adjusting each bolt & nut.

● Make sure everything is stable before driving.

