

## FASHION CARRIER (CENTER)

CODE	(BLACK) 80-539-14461	(WHITE) 80-539-14462
APPLICATION	CROSS CUB 50 (AA06) / CROSS CUB 110 (JA45/60)	

Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

### ATTENTION (MUST READ)

- This instruction sheet is for the instruction for genuine condition.
- This product is designed and made exclusive for application vehicles, do not use other models. Do not modify the way which is not listed or it will cause damage and trouble.
- We are not responsible for violation of law or damages and accidents caused by assembling mistake and improper setting.
- Please ask authorized mechanic for assembling and setting.
- Refer to the manufacturer service manual when installation.
- Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.

FIGURE	PACKING LIST			BLACK	WHITE
	NAME	CODE	QTY		
1	CENTER CARRIER	BLACK	539-1153251	x1	-
	STAY (LONG)	BLACK	-	x1	-
	STAY (SHORT)	BLACK	-	x1	-
	END CAP 15.9mm	BLACK	998-0900004	x2	-
	CENTER CARRIER	WHITE	539-1153281	-	x1
	STAY (LONG)	WHITE	-	-	x1
	STAY (SHORT)	WHITE	-	-	x1
	END CAP 15.9mm	WHITE	998-0900010	-	x2
2	SPACER COLLAR	6.2x13xL3	093-9000005	x3	x3
3	FLANGE COLLAR	13x6xL2.5	093-0900007	x2	x2
4	WASHER	6x13xT1.0mm	090-0900006	x8	x8
5	CAP BOLT	M6x20	060-0500020	x2	x2
6	FLANGE HEXAGON BOLT	M 6x12 BLACK	062-0561012	x2	-
	FLANGE HEXAGON BOLT	M 6x12	062-0563012	-	x2
7	SPRING WASHER	6mm	091-0500006	x2	x2
8	NUT	6mm	001-0500006	x2	x2
9	STEPPED COLLAR		539-1446202	x1	x1

- ⊘ Do not apply excessive force to carrier such as using rope or tie to deliver the vehicle. It might damage the center carrier or surrounding parts.
- ⊘ Do not overweight on carrier. It might damage the carrier. **(Weight limit : 1.0kg)**
- ⚠ Do not apply excessive force like lifting the vehicle using carrier or back rest. When you turning the vehicle, use it to helping tool.

## HOW TO INSTALL

- ※ If there is a hard degradation like a blem, fatigue and wear etc on the reuse parts, please change to new ones.
- Install center carrier temporarily with attached bolts and genuine bolt by using main pipe cover installation bolt position.
- ※ **Tighten bolts alternately evenly while adjusting all balance.** Tighten once each might be unable to install correctly.
- ※ If there is a gap because of the tolerance, please adjust by attached washer ④ on main pipe cover installation bolt position.

