





FLOATING DISC ROTOR (220mm)						
(PLATE / PIN) CODE	BLACK / RED 500-1432700	BLACK / GOLD 500-1432710	RED / BLACK 500-1432720	GOLD / BLACK 500-1432730	BLACK / BLACK 500-1432740	GOLD / RED 500-1432750
APPLICATION	MONKEY 125 (JB02) Cannot use for ABS vehicle. GROM (FNO,JC61-1000001 ~ 1299999/JC61-1300001 ~) Dio 110 (JF31) /SH MODE (JF51) PCX125 (JF56/JF28) /PCX150 (KF12/KF18)					
REMARK	○Disc O.D.: φ220 ○Hole diameter: φ58 ○P.C.D: φ78 ○Installation hole diameter: φ10.5 ○Thickness: 4mm ○pad touching width: 36mm					

● Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

### ATTENTION (MUST READ)

- This product increases braking by make normal disc rotor larger O.D. After installation, the brake feeling and handling stability is different from genuine. Be careful of it.
- This product is designed and made exclusive for the application vehicles. Do not use other models. Do not modify the way which is not listed or it will cause damage and trouble.
- We are not responsible for violation of law or damages and accidents caused by assembling mistake and improper setting.
- Please ask authorized mechanic for assembling and setting. Ask a specialist at speciality shop if you do not understand the role of the surrounding parts.
- Refer to the manufacturer service manual when installation.
- Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.
- Make sure braking effect is usual and any suspicious thing around brake.
- This instruction sheet is for the instruction for genuine condition.
- Brake pad, disc rotor and brake fluid are consumable items. Please change to new ones if over the usage limit or deterioration.
- Please bleed air of brake fluid regularly.

			
If there is trouble on brake and related parts may cause of big accident immediately. Handle with extreme care.	Do not modify the way which is not listed or it will cause damage and trouble.	This instruction sheet is for the person who has basic knowledge for maintenance. Do not operate if you do not have skill and knowledge.	The license is not required for some brake maintenance, but doing operation by beginner is prohibited. Ask mechanic if you do not have skill and knowledge.

### PACKING LIST ( ) is 1SET QTY.

FIGURE	NAME	CODE	QTY
A1	FLOATING DISC ROTOR 220mm	-	× 1
B	FLOATING PIN SET	RED	500-0700920
		BLACK	500-0700921
		GOLD	500-0700922
B1	FLOATING PIN	RED	500-0700908 (× 1)
		GOLD	500-0700911 (× 1)
		BLACK	500-0700912 (× 1)
B2	FLOATING WAVE WASHER	500-0700902	(× 1)
B3	PULLEY WASHER 14 × 20 × T0.5	463-1071002	(× 1)
B4	FLOATING E RING	500-0700909	(× 1)
C1	DISC ROTOR INNER PLATE	BLACK	500-1432701
		RED	500-1432702
		GOLD	500-1432703
D1	OUTER DISC PLATE	500-1418790	× 1

### HOW TO INSTALL ATTENTION!

- ※ When installing disc rotor, removing / installing wheel is difficult, therefore removing surrounding parts might be required.
- ※ Basically, reuse genuine parts if it is not attached.
- ※ If there is a hard degradation like a blem, fatigue and wear etc on the reuse parts, please change to new ones.
- When removing / installing, float front tire and fix the vehicle not to fall.
- Refer to the illustration below, install disc rotor and caliper bracket.
- ※ Must to apply screw lock to caliper bracket installation bolt and disc rotor installation bolt.
- ※ When installing disc rotor to wheel, recommend to sand disc to caliper first to install.  
(If installing disc rotor to wheel first, it might unable to install caliper.)

● Tighten each parts with specified torque, then check brake works normally before riding.

### ● INSTALLATION REFERENCE ILLUSTRATION

