STAINLESS STEEL SPORTY DOWN TYPE MUFFLER for SUPER CUB110

543-1439400

CODE


APPLICATION

ATION SUPER CUB110 (JA44) / CROSS CUB110 (JA45)

Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

ATTENTION (MUST READ)

- •This product increases exhausting system and bring out special performance. However, setting up is required. If you don't, it might cause of decrease performance, burning and trouble. Please understand before installng.
- •We are not responsible for violation of law or damages and accidents caused by assembling mistake and improper setting.
- •This instruction sheet is for the instruction for stock condition. Do not modify the way which is not listed or it will cause damage and trouble.
- •This product is designed and made exclusive for application models, do not use other models.
- •Out put characteristic is different from stock, please ride safely.
- •Please ask authorized mechanic for assembling and setting. Ask a specialist at specialty shop if you do not understand the role of the surrounding parts.
- •Refer to the manufacturer service manual when installation.
- •Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving.



*() is 1 set QTY.

HED PARTS		
NAME	CODE	QTY
STAINLESS STEEL SPORTY DOWN MUFFLER	-	$\times 1$
N PARTS (SOLD SEPARATELY)		
MUFFLER GASKET (XH-06)	963-1000006	(× 2)
	NAME STAINLESS STEEL SPORTY DOWN MUFFLER N PARTS (SOLD SEPARATELY)	NAME CODE STAINLESS STEEL SPORTY DOWN MUFFLER - N PARTS (SOLD SEPARATELY) -

(This is just a installation illustration, please refer to the manufacturer service manual.)

- *Basically, reuse genuine parts if it is unattached. If there is a hard degradation like a blem, fatigue and wear etc on the reuse parts, please change to new ones.
- •Install Kitaco muffler temporarily with attached parts as illustration. (Refer to the illustration.)
- *Recommend to change muffler gasket to new one (sold separtely).

*When installing muffler, removing step ease to install.


•Install removed srock parts, tighten with specified torque while adjusting each parts. Make sute not to leak exhaust.


INSTALLATION ILLUSTRATION

POINT!

If unable to install muffler correctly, move pivot shaft to swing arm side to install temporarily. (Refer to the illustration below.)

When moving pivot shaft, remove L pivot cover on left side.





ATTENTION!

After riding a lot, surface of the product (especially exhaust pipe) might change its color, but it's not unusual. If want to remove burning, please use specified chemicals that sold commercially.

- If starting engine with oil or dirt, it changes color or burned (only that place). Please wipe it with degreaser before starting engine.
- •Do not leave this product with water. It might cause of tarnish or rust.

HOW TO TAKE CARE

•Rust and corrosion caused by surface oxidation is caused by exhaust high heat. Genuine muffler is the same. This is characteristic, which cannot avoid. However, it only occurs to surface. Applying heat resist silicone wax to delay tarnish.

210324 Y-N 3-8-13 NAGATA,

HIGASHI-OSAKA, OSAKA,JAPAN https://www.kitaco.co.jp/