CENTER LOCK NUT WRENCH

CODE: 674-1432900

This is required specific tool when removing / installing honda mission vehicle clutch center lock nut. Please use clutch outer holder or gear holder together.

•Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

ATTENTION (MUST READ) -

• This product is designed and made exclusive for application models, do not use other models. Do not modify the way which is not listed or it will cause damage and trouble.

- •We are not responsible for violation of law or damages and accidents caused by assembling mistake and improper setting.
- •Please ask authorized mechanic for assembling and setting. Ask a specialist at specialty shop if you do not understand the role of the surrounding parts.
- •Refer to the manufacturer service manual when installation.

•Bolts and nuts may get loosen by engine vibration. Make sure not to loosen any bolts and nuts before driving. ※Metal/resin products get discolored/rust for ages as well as how to use. Please understand when using.

APPLICATION

For removing / installing of MONKEY / CUB ENGINE, GROM, etc MANUAL CLUTCH, AUTO CLUTCH, NSR50/80, NS-1 CLUTCH

MAIN APPLICATION	SIZE]
LATEST MONKEY / GORILLA /	24	
MONKEY BAJA Fno,Z50J-1300017~		# 30
MONKEY R / RT	24	# 30
DAX (ST50)	24	
CUB (C50 / 70 / 90)	24	
CUB 100EX	24	
NS50F / NSR50 / 80 / NS-1 / etc	24	# 24
GROM	24/30	4 8 9

ATTENTION!

•Please use 1/2 inch (12.7mm) torque wrench.

• Please use this product with clutch outer holder or gear holder together.

**Do not use with impact wrench or punch by hummer. It might cause of break.

HOW TO STORAGE AND TAKE CARE

Under special environment (high humidity, etc) migh cause of rust. Please apply anti-rust, etc when using and storage.



IN CASE OF GROM

Fix primary drive gear and driven gear by gear holder (674-0510900) sold separately, then remove auto filter rotor lock nut / clutch center lock nut.



