POWER SUPPLY EXTRACT HARNESS

APPLICATION SUPER CUB 50 STANDARD (AA04) / 110 STANDARD (JA007/10)

SUPER CUB 50 (AA09) / 110 (JA44) / SUPER CUB 50 PRO (AA04-3000001~) / 110 PRO (JA10-1100001~) / CROSS CUB (JA10-4000001~) are NOT usable, because power supply harness coupler is different.

\*\*NOT FOR HIGH CURRENT ACCESSORIES SUCH AS AMPLIFIER & COMPRESSOR etc.

Thank you for purchasing Kitaco product. Read and understand the instruction before installing.

## ☐ ATTENTIONS (MUST READ)

- ▼Install POWER SUPPLY EXTRACT HARNESS, referring to below instruction.
- We are not responsible for violation of law of or damages and accidents caused by assembling mistake and improper setting.
- Please ask authorized mechanic for assembling and setting. Ask a mechanic or a specialist at a specialty shop for assembling and setting if you do not understand the role of the surrounding parts.
- Refer to the HONDA service manual for each vehicle when installing.
- POWER SUPPLY EXTRACT HARNESS is designed and made exclusive for SUPER CUB 50 STANDERD (AA04) / 110 STANDERD (JA007/10), do not use on other models.
- Make sure there is no abnormal thing in vehicle and engine starts normally.
- Make sure there is no bolt / nut / coupler terminal left or loosen before running.
- $\bullet$  Please give this instruction together when your vehicle is sold.

**\*\*NOT FOR HIGH CURRENT ACCESSORIES SUCH AS AMPLIFIER & COMPRESSOR etc.** 



This instruction sheet is for the person who has basic knowledge for maintenance. Do not operate if you do not have skill and knowledge.

