POWER SUPPLY EXTRACT HARNESS

(YAMAHA type-3)

CODE:756-9000320

APPLI CATION (YAMAHA deputation motorcycle) XOnly for domestic specification

SR400 (3HT/R/U/V/W/X/Y/B0H1) FNo,RH03J

ATTENTION

XNOT FOR HIGH CURRENT ACCESSORIES SUCH AS AMPLIFIER & COMPRESSOR etc.

Thank you for purchasing Kitaco product. Read and understand the instruction before installing.


☐ ATTENTIONS (MUST READ)

- ▼Install POWER SUPPLY EXTRACT HARNESS, referring to below instruction.
- We are not responsible for violation of law of or damages and accidents caused by assembling mistake and improper setting.
- Please ask authorized mechanic for assembling and setting. Ask a mechanic or a specialist at a specialty shop for assembling and setting if you do not understand the role of the surrounding parts.
- Refer to the YAMAHA service manual for each vehicle when installing.
- POWER SUPPLY EXTRACT HARNESS is designed and made exclusive for specific models, do not use on other models.
- Make sure there is no abnormal thing in vehicle and engine starts normally.
- Make sure there is no bolt / nut / coupler terminal left or loosen before running.
- Please give this instruction together when your vehicle is sold.

****NOT FOR HIGH CURRENT ACCESSORIES SUCH AS AMPLIFIER & COMPRESSOR etc.**




This instruction sheet is for the person who has basic knowledge for maintenance. Do not operate if you do not have skill and knowledge.



ATTENTION!

☐ GND — (GROUND) | ※If the voltage of GND & ACC and the ACC +(POWER SUPPLY ACCESSORY) | voltage from battery are different, replace the GND terminal positions on the frame.



Inside head right cover

Front break lamp switch

2P (White) COUPLER

The ground terminal is tightened together to the unpainted part such as the frame.